



At the top of the opening to the radiator you will find either two plastic screws or two bolts. If plastic screws, remove and discard these and fix the supplied brackets with the supplied bolts to these holes. If bolts, undo them and fix the supplied brackets under them.

The brackets face forwards and take the top of the grille as shown in the illustration.

Roughly line the grille up with the opening, and note that the lower bracket attached to the grille lines up with a plastic fitting roughly in the center of the lower of the opening. Remove and discard this fitting.

Check that the bend of the grille follows the line of the car. Now hook the top of the grille in to the top brackets and gently push the bottom of the grille in to place until the bolt on the lower fixed bracket lines up with the hole. Push a slim screwdriver through the mesh and push the lower bracket down so that the bolt goes through the hole and secure with the supplied nut from underneath.

Scimitar International Ltd.  
Unit 4, Cluster Industrial Estate  
Rodney Road, Portsmouth  
Hampshire, PO4 8ST

**Tel:** 0845 345 2384 **Fax:** 0845 345 2385

**Website:** <http://www.mx5parts.co.uk>

© Copyright 2002, Scimitar International Ltd.