Fitting Instructions - NC Headlamp Eyelids Art.Nr. NC0-0520



In order to achieve a perfect fit of the headlight covers a dismantling of the front bumper is needed.

Place the cut out template into the headlamp, cut and mark with a water-soluble pen the position on the headlight. (Fig. 1)

Remove the screws on the front splash guard under the car. (Fig. 2)





Fig. 1 Fig. 2

Remove the front wheels to reduce the inner fender. (Fig. 3) Loosen the nuts to the now vacant fenders combined with the front apron. (Fig. 4)





Fig. 4

Now remove the screws in the engine compartment. (Fig. 5)



Fig. 5

Fitting Instructions - NC Headlamp Eyelids

Art.Nr. NC0-0520



The front bumper can now be removed.

Now glue the headlight covers on the headlights (Fig. 6) using the marks you made on the lamps earlier as a guide.



Fig. 6

Now re-install the front bumper again, stand back and admire your handy work!

